



Instruction Manual
Rough Riders

Pirata

Rough Riders

Movement

CYS 5103, 11 ½ "", automatic, diameter 25.6 mm, height 3.6 mm, power reserve 42 hours, 25 jewels, frequency: 28800 A/h.

Functions

Hours, minutes, central seconds and date.

Starting the Watch

If the watch has stopped, a few turns of the crown (pos.1) clockwise are sufficient to restart it. When worn, the natural wrist movement will be sufficient to keep the charge.

Handling and Corrections

- Pull the crown to the point of resistance (position 2), then rotate it in the counterclockwise direction to set the date.
- Pull the crown to the point of resistance (position 3) to stop the watch, then rotate the crown clockwise or counterclockwise to set the time.

Warning

Do not fix the date when the hands are between 09:00 P.M. and 00:30.

Maintenance

To ensure a service that meets the brand's standards, any servicing of your watch must be carried out by Cuervo y Sobrinos customer service or an approved watchmaker. Whenever repairs are made during the warranty period, you must present the proof of warranty, with the date and name of the retailer where the watch was purchased.

- A - Minutes hand
- B - Hours hand
- C - Seconds hand
- D - Crown
- E - Date indicator



