



Instruction Manual
Prominente Doble Tiempo

Prominente

Doble Tiempo

Functions

Hours, minutes, date, day date, second time zone with 24 hours indication.

Starting the Watch

If the watch has stopped, a few turns of the crown (pos.1) clockwise are sufficient to restart it. When worn, the natural wrist movement will be sufficient to keep the charge.

Handling and Corrections

- Upper Movement: Pull the crown to the point of resistance (position 2) to stop the watch, then rotate the crown counterclockwise to set the time.
- Bottom Movement: Pull the crown to the point of resistance (position 2) to stop the watch, then rotate the crown counterclockwise to set the time.

Warning

Do not fix the date when the hands are between 09:00 P.M. and 00:30.

Maintenance

To ensure a service that meets the brand's standards, any servicing of your watch must be carried out by Cuervo y Sobrinos customer service or an approved watchmaker. Whenever repairs are made during the warranty period, you must present the proof of warranty, with the date and name of the retailer where the watch was purchased.

Upper Movement

- A - Hours hand
- B - Minutes hand
- C - Crown

Lower Movement

- D - Hours hand
- E - Crown
- F - Minutes hand



