



Instruction Manual
Historiador Gran Reserva

Historiador

Gran Reserva

Movement

La Joux-Perret G100 Automatic. Power Reserve 68 hours.

Functions

Hours, minutes, central seconds, and date display at 6h.

Starting the Watch

If the watch has stopped, turn the crown in Position I clockwise (upwards) a few times to restart it. When worn regularly, the natural movement of the wrist will keep the watch charged.

Handling and Corrections

- Manual Winding: With the crown in Position I, rotate it clockwise (upwards) to wind the watch manually.
- Date Setting: Pull the crown to Position II and turn it clockwise (upwards) to set the date.
- Time Setting: Pull the crown to Position III and turn it counterclockwise (downwards) to set the time..

Warning

Do not fix the date when the hands are between 11:00 P.M. and 03:00 AM.

Maintenance

To ensure a service that meets the brand's standards, any servicing of your watch must be carried out by CyS SA customer service or an approved watchmaker. Whenever repairs are made during the warranty period, you must present the proof of warranty, with the date and name of the retailer where the watch was purchased.

- I. Running position and manual winding
- II. Date setting
- III. Time setting

- 1. Hour hand
- 2. Minute hand
- 3. Small second
- 4. Date display



