



**Instruction Manual
Hemingway GMT**

Historiador

Hemingway GMT

Movement

CYS 8122 , base Soprod C125, 11 ½ "", automatic, diameter: 26.20 mm, height: 4.10 mm, 42 hours, 25 jewels, 28800 A/h, finished oscillating weight with engraving.

Functions

Hours, minutes, central seconds date display in window, GMT central.

Starting the Watch

If the watch has stopped, a few turns of the crown (pos.1) clockwise are sufficient to restart it. When worn, the natural wrist movement will be sufficient to keep the charge.

Handling and Corrections

Winding stem with 3 positions:

- Pos.1 Running position and manual winding
- Pos.2 Quick date correction and GMT central
- Pos.3 Time setting with stop-second

Warning

Do not fix the date when the hands are between 09:00 P.M. and 00:30.

Maintenance

To ensure a service that meets the brand's standards, any servicing of your watch must be carried out by Cuervo y Sobrinos customer service or an approved watchmaker. Whenever repairs are made during the warranty period, you must present the proof of warranty, with the date and name of the retailer where the watch was purchased.

- A - Minutes hand
- B - Hours hand
- C - Seconds hand
- D - Crown
- E - Date indicator
- F - GMT hand



